



BOSCH EDC15C5-X EEPROM 95P08 (P)
BOSCH EDC15C6 EEPROM 95P08 (P)
BOSCH EDC15C7 EEPROM 95P08 (P)
BOSCH EDC16C8 EEPROM 95160 (P)
BOSCH EDC16C9 EEPROM 95160 (P)
BOSCH M2.10.3 EEPROM 24C02 (T.P)
BOSCH M2.10.4 EEPROM 24C02 (T.P)
BOSCH ME7.1.1 EEPROM 25/95080 (P)
BOSCH MED7.6.1 EEPROM 25/95080 (P)
BOSCH MED7.6.2 EEPROM 25/95080 (P)



BOSCH EDC15M-5.X EEPROM 24C04 (T)
BOSCH EDC15P EEPROM 24C04 (T)
BOSCH EDC15P-6 MICRO 1037355944 EEPROM 24C04 (T)
BOSCH EDC15V EEPROM 24C04 (T)
BOSCH EDC15VM+ EEPROM 24C04 (T)
BOSCH EDC16CP34 EEPROM 95320 (T)
BOSCH EDC16U1 EEPROM 95320 (T)
BOSCH EDC16U31 EEPROM 95320 (T)
BOSCH EDC16U34 EEPROM 95320 (T)
BOSCH M3.8.X EEPROM 24C02 (T)
BOSCH M5.4.1 EEPROM 24C02 (T)
BOSCH M5.9.2 EEPROM 24C02 (T)
BOSCH MSA EDC15-X EEPROM 24C02 ALL ECU (T)
SIEMENS SIMOS 2.X 2 PLUG FLASH 29F200 (T)
SIEMENS SIMOS1.X 1 PLUG EEPROM 93C56 (T)
SIEMENS SIMOS2.X 2 PLUG EPROM 27C010 (T)



BOSCH MSA 15.5 EPROM 93C46 (T)



BOSCH EDC15C2-6 EEPROM 95P08 (T)
BOSCH EDC15C6 FLASH 29F400 EURO 3 (T)
BOSCH EDC15C7 EEPROM 95P08 (P)
BOSCH EDC15C7 FLASH 29F400 EURO 3 (T)
BOSCH MA3.0 EEPROM 93CS46 (T.P)
BOSCH MA3.1 EEPROM 93CS46 (T.P)
BOSCH MP3.1 EEPROM 93CS46 (T.P)
BOSCH MP3.2 EEPROM 93CS46 (T.P)
BOSCH MP5.1 EEPROM 93CS46 (T.P)
BOSCH MP5.1.1 EEPROM 93CS46 (T.P)
BOSCH MP5.2 EEPROM 93CS46 (T.P)
BOSCH MP7.0 EEPROM 24C02 (P)
BOSCH MP7.2 EEPROM 24C02 (T.P)
BOSCH MP7.3 EEPROM 24C02 (T.P)
MAGNETI MARELLI 48P.XX FLASH 29F400 (P) ROLLING CODE RESET
MAGNETI MARELLI 48P3X EEPROM 25/95080 (T.P)
MAGNETI MARELLI 4MP.XX FLASH 29F200 (T.P) ROLLING CODE RESET
MAGNETI MARELLI 5NP EEPROM 95160 (P)
MAGNETI MARELLI 6LPX MCU ST10F280 (P)
MAGNETI MARELLI G6 MCU 68HCA1 (T.P)
MAGNETI MARELLI IAW 8P.XX MCU 68HC11A1 (T.P)



DELPHI TRW EEPROM 25/95080 (P)
SIEMENS SIRIUS32 FLASH 29F200 (P) ROLLING CODE RESET
SIEMENS SIRIUS34 FLASH 29F200 (P) ROLLING CODE RESET



KEMSCO D3 FLASH 29F200 (P) ROLLING CODE RESET



BOSCH EDC15C2-6 EEPROM 95P08 (T)
BOSCH EDC15C5-X EEPROM 95P08 (P)
BOSCH EDC15C6 EEPROM 95P08 (P)
BOSCH EDC15C6 FLASH 29F400 EURO 3 (T)
BOSCH EDC15C7 EEPROM 95P08 (P)
BOSCH EDC15C7 FLASH 29F400 EURO 3 (T)

BOSCH EDC15C8-1.31 EEPROM 95320 (P)
BOSCH EDC16C39 JTD 1.9L EEPROM 95320 (P) + CRASH RESET
BOSCH EDC16C8 EEPROM 95160 (P)
BOSCH EDC16C9 EEPROM 95160 (P)
BOSCH M1.7.3 EEPROM 24C02 (T.P)
BOSCH M2.10.3 EEPROM 24C02 (T.P)
BOSCH M2.10.4 EEPROM 24C02 (T.P)
BOSCH MP3.2 EEPROM 93CS46 (T.P)
LUCAS DCU3F EEPROM 25/95080 (P)
MAGENTI MARELLI MJD 6JF EEPROM 95320 (P)
MAGNETI MARELLI 48P.XX FLASH 29F400 (P) ROLLING CODE RESET
MAGNETI MARELLI 48P3X EEPROM 25/95080 (T.P)
MAGNETI MARELLI 49F/4GF EEPROM 25/95040 (T)
MAGNETI MARELLI 4AF EEPROM 95160 (P)
MAGNETI MARELLI 4AF.XX EEPROM 95160 (T)
MAGNETI MARELLI 4MP.XX FLASH 29F200 (T.P) ROLLING CODE RESET
MAGNETI MARELLI 4SF MCU ST10F280 (P)
MAGNETI MARELLI 59F.XX MCU / EEPROM ST10F168/269 (P)
MAGNETI MARELLI 59FBTX EEPROM 25/95160(P)
MAGNETI MARELLI 5AF.XX MCU / EEPROM ST10F168/269 (P)
MAGNETI MARELLI 5NF.XX EEPROM 95160 (P)
MAGNETI MARELLI 5NFXX EEPROM 95160 T

IVECO

BOSCH EDC15P EEPROM 24C04 (T)
BOSCH EDC15P-6 MICRO 1037355944 EEPROM 24C04 (T)
BOSCH EDC15V EEPROM 24C04 (T)
BOSCH EDC16C3 EEPROM 95160 (P)
BOSCH M3.8.1 EEPROM 24C02 (T)
BOSCH ME7.1 EEPROM 25/95040 T
BOSCH MSA EDC15-X EEPROM 24C02 ALL ECU (T)

IVECO

BOSCH M.S 6.3 EEPROM 24C16 (T.P)



BOSCH EDC15C2-6 EEPROM 95P08 (T)
BOSCH EDC15C5-X EEPROM 95P08 (P)
BOSCH EDC15C6 EEPROM 95P08 (P)
BOSCH EDC15C6 FLASH 29F400 EURO 3 (T)
BOSCH EDC15C7 EEPROM 95P08 (P)
BOSCH EDC15C7 FLASH 29F400 EURO 3 (T)
BOSCH EDC15C8-1.31 EEPROM 95320 (P)
BOSCH EDC16C39 JTD 1.9L EEPROM 95320 (P) + CRASH RESET
BOSCH EDC16C8 EEPROM 95160 (P)
BOSCH EDC16C9 EEPROM 95160 (P)
BOSCH M1.7.3 EEPROM 24C02 (T.P)

BOSCH M2.10.3 EEPROM 24C02 (T.P)
BOSCH M2.10.4 EEPROM 24C02 (T.P)
BOSCH MP3.2 EEPROM 93CS46 (T.P)
LUCAS DCU3F EEPROM 25/95080 (P)
MAGNETI MARELLI MJD 6JF EEPROM 95320 (P)
MAGNETI MARELLI 48P.XX FLASH 29F400 (P) ROLLING CODE RESET
MAGNETI MARELLI 48P3X EEPROM 25/95080 (T.P)
MAGNETI MARELLI 49F/4GF EEPROM 25/95040 (T)
MAGNETI MARELLI 4AF EEPROM 95160 (P)
MAGNETI MARELLI 4AF.XX EEPROM 95160 (T)
MAGNETI MARELLI 4MP.XX FLASH 29F200 (T.P) ROLLING CODE RESET
MAGNETI MARELLI 4SF MCU ST10F280 (P)
MAGNETI MARELLI 59F.XX MCU / EEPROM ST10F168/269 (P)
MAGNETI MARELLI 59FBTX EEPROM 25/95160(P)
MAGNETI MARELLI 5AF.XX MCU / EEPROM ST10F168/269 (P)
MAGNETI MARELLI 5NF.XX EEPROM 95160 (P)
MAGNETI MARELLI 5NFXX EEPROM 95160 T



BOSCH MSA 15.5 EPROM 93C46 (T)
MEMS MKC EEPROM 93C46 (T)



MEMS MKC EEPROM 93C46 (T)



SIEMENS EMS 2 FLASH 29F400 (P) ROLLING CODE RESET



BOSCH EDC15C3 EEPROM 95P08 (P)



BOSCH EDC15C3 EEPROM 95P08 (P)

DELPHI TRW EEPROM 25/95080 (P)



BOSCH EDC15C3 EEPROM 95P08 (P)

BOSCH EDC15M EEPROM 24C04 (P)

BOSCH M1.5.X EEPROM 24C02 T

MAGNETI MARELLI MJD 6JF GM EEPROM 95320 (P)

SIMTEC 56.1 EEPROM 93C56 (T)

SIMTEC 56.1 EEPROM 93C56 (P)



BOSCH EDC15C2-6 EEPROM 95P08 (T)

BOSCH EDC15C6 EEPROM 95P08 (P)

BOSCH EDC15C6 FLASH 29F400 EURO 3 (T)

BOSCH EDC15C7 FLASH 29F400 EURO 3 (T)

BOSCH MA3.0 EEPROM 93CS46 (T.P)

BOSCH MA3.1 EEPROM 93CS46 (T.P)

BOSCH MP3.1 EEPROM 93CS46 (T.P)

BOSCH MP3.2 EEPROM 93CS46 (T.P)

BOSCH MP5.1 EEPROM 93CS46 (T.P)

BOSCH MP5.1.1 EEPROM 93CS46 (T.P)

BOSCH MP5.2 EEPROM 93CS46 (T.P)

BOSCH MP7.0 EEPROM 24C02 (P)

BOSCH MP7.2 EEPROM 24C02 (T.P)

BOSCH MP7.3 EEPROM 24C02 (T.P)

BOSHC EDC 1.3.8 MSA11-3 EEPROM 93C46 DX & SX (T.P)

MAGNETI MARELLI 48P.XX FLASH 29F400 (P) ROLLING CODE RESET

MAGNETI MARELLI 48P3X EEPROM 25/95080 (T.P)

MAGNETI MARELLI 4MP.XX FLASH 29F200 (T.P) ROLLING CODE RESET

MAGNETI MARELLI 5NP EEPROM 95160 (P)



BOSCH EDC16C3 EEPROM 95160 (P)
BOSCH EDC15.X 1 PLUG EEPROM 24C02 (P)
BOSCH EDC15.X 2 PLUG EEPROM 24C04 (P)
BOSCH EDC15C3 EEPROM 95P08 (P)
BOSCH MP7.0 EEPROM 24C02 (P)
DELPHI TRW EEPROM 25/95080 (P)
LUCAS DCU3R EEPROM 25/95080 (P)
SIEMENS EMS3132 FLASH 29F200 (P) ROLLING CODE RESET
SIEMENS EMS3134 FLASH 29F400 (P) ROLLING CODE RESET
SIEMENS SIRIUS 35 FLASH 29F400 (P) ROLLING CODE RESET
SIEMENS SIRIUS32 FLASH 29F200 (P) ROLLING CODE RESET
SIEMENS SIRIUS34 FLASH 29F200 (P) ROLLING CODE RESET
SIEMENS SIRIUS34 FLASH 29F400 (P) ROLLING CODE RESET



BOSCH M.S 6.3 EEPROM 24C16 (T.P) TRUKS



MEMS MKC EEPROM 93C46 (T)



BOSCH EDC1.3.1 MSA11 EEPROM 93C46 DX (T)
BOSCH EDC15M-5.X EEPROM 24C04 (T)
BOSCH EDC15P EEPROM 24C04 (T)
BOSCH EDC15P-6 MICRO 1037355944 EEPROM 24C04 (T)
BOSCH EDC15V EEPROM 24C04 (T)
BOSCH EDC15VM+ EEPROM 24C04 (T)
BOSCH EDC16CP34 EEPROM 95320 (T)
BOSCH EDC16U1 EEPROM 95320 (T)
BOSCH EDC16U31 EEPROM 95320 (T)
BOSCH EDC16U34 EEPROM 95320 (T)
BOSCH M3.8.X EEPROM 24C02 (T)
BOSCH M5.4.1 EEPROM 24C02 (T)
BOSCH M5.9.2 EEPROM 24C02 (T)
SIEMENS SIMOS 2.X 2 PLUG FLASH 29F200 (T)
SIEMENS SIMOS1.X 1 PLUG EEPROM 93C56 (T)
SIEMENS SIMOS2.X 2 PLUG EPROM 27C010 (T)



BOSCH EDC1.3.1 MSA11 EEPROM 93C46 DX (T)
BOSCH EDC15M-5.X EEPROM 24C04 (T)
BOSCH EDC15P EEPROM 24C04 (T)
BOSCH EDC15P-6 MICRO 1037355944 EEPROM 24C04 (T)
BOSCH EDC15V EEPROM 24C04 (T)
BOSCH EDC15VM+ EEPROM 24C04 (T)
BOSCH EDC16CP34 EEPROM 95320 (T)
BOSCH EDC16U1 EEPROM 95320 (T)
BOSCH EDC16U31 EEPROM 95320 (T)
BOSCH EDC16U34 EEPROM 95320 (T)
BOSCH M3.8.X EEPROM 24C02 (T)
BOSCH M5.4.1 EEPROM 24C02 (T)
BOSCH M5.9.2 EEPROM 24C02 (T)
BOSCH MSA EDC15-X EEPROM 24C02 ALL ECU (T)
SIEMENS SIMOS 2.X 2 PLUG FLASH 29F200 (T)
SIEMENS SIMOS1.X 1 PLUG EEPROM 93C56 (T)
SIEMENS SIMOS2.X 2 PLUG EPROM 27C010 (T)



BOSCH EDC15C2-6 EEPROM 95P08 (T)
DELPHI TRW EEPROM 25/95080 (P)
LUCAS DCU3R EEPROM 25/95080 (P)
MAGNETI MARELLI MJD 6JF GM EEPROM 95320 (P)
SIEMENS SID 801 5WS4 EEPROM 93C56 (T.P)



BOSCH EDC16CXX EEPROM 95160 (P)



BOSCH EDC15.X 1 PLUG EEPROM 24C02 (P)
SIEMENS SIRIUS32 FLASH 29F200 (P) ROLLING CODE RESET
Delphi TRW 95080



BOSCH EDC1.3.1 MSA11 EEPROM 93C46 DX (T)
BOSCH EDC15M-5.X EEPROM 24C04 (T)
BOSCH EDC15P EEPROM 24C04 (T)
BOSCH EDC15P-6 MICRO 1037355944 EEPROM 24C04 (T)
BOSCH EDC15V EEPROM 24C04 (T)
BOSCH EDC15VM+ EEPROM 24C04 (T)
BOSCH EDC16CP34 EEPROM 95320 (T)
BOSCH EDC16U1 EEPROM 95320 (T)
BOSCH EDC16U31 EEPROM 95320 (T)
BOSCH EDC16U34 EEPROM 95320 (T)
BOSCH M3.2.1 EEPROM 24C02 (T)
BOSCH M3.8.X EEPROM 24C02 (T)
BOSCH M5.4.1 EEPROM 24C02 (T)
BOSCH M5.9.2 EEPROM 24C02 (T)
SIEMENS SIMOS 2.X 2 PLUG FLASH 29F200 (T)
SIEMENS SIMOS1.X 1 PLUG EEPROM 93C56 (T)
SIEMENS SIMOS2.X 2 PLUG EPROM 27C010 (T)